



# Support Booting from QSPI Flash in Linux i.MX RT1050

---

Detailed Requirements and  
Design

rm2595-drad-1\_1.doc

<i>RM:</i>	2595
<i>Revision:</i>	1.1
<i>Date:</i>	8/13/2018

## TABLE OF CONTENTS

<b>1.</b>	<b>OVERVIEW .....</b>	<b>3</b>
<b>2.</b>	<b>REQUIREMENTS .....</b>	<b>3</b>
2.1.	Detailed Requirements .....	3
2.2.	Detailed Non-Requirements .....	4
<b>3.</b>	<b>DESIGN .....</b>	<b>4</b>
3.1.	Design: U-Boot Boot from QSPI Flash.....	4
3.2.	Design: U-Boot sf_ Commands .....	4
3.3.	Design: U-Boot Environment in QSPI Flash .....	4
3.4.	Design: U-Boot Install Images to QSPI Flash.....	5
3.5.	Design: Linux Boot from QSPI Flash .....	5
3.6.	Design: Linux Device Driver for QSPI Flash and Flash File System .....	6
<b>4.</b>	<b>TEST PLAN.....</b>	<b>6</b>
4.1.	Secure Download Area.....	6
4.2.	Downloadable Files.....	6
4.3.	Test Set-Up.....	6
4.3.1.	<i>Hardware Set-Up .....</i>	<i>6</i>
4.3.2.	<i>Software Set-Up .....</i>	<i>7</i>
4.4.	Detailed Test Plan .....	8
4.4.1.	<i>Test Plan: U-Boot Boot from QSPI Flash.....</i>	<i>8</i>
4.4.2.	<i>Test Plan: U-Boot sf_ Commands .....</i>	<i>9</i>
4.4.3.	<i>Test Plan: U-Boot Environment in QSPI Flash .....</i>	<i>9</i>
4.4.4.	<i>Test Plan: U-Boot Install Images to QSPI Flash .....</i>	<i>10</i>
4.4.5.	<i>Test Plan: Linux Boot from QSPI Flash.....</i>	<i>10</i>
4.4.6.	<i>Test Plan: Linux Device Driver for QSPI Flash and Flash File System.....</i>	<i>11</i>

## 1. Overview

The following is a high-level overview of the problem being resolved by this project:

This project develops support for booting from QSPI Flash in the Linux i.MX RT1050 BSP.

## 2. Requirements

### 2.1. Detailed Requirements

The following are the requirements for this project:

1. Support booting of U-Boot from QSPI Flash, with no reliance on presence of SD Card or any other storage devices.
  - *Rationale:* Explicit customer requirement.  
*Implementation:* Section: "Design: U-Boot Boot from QSPI Flash".  
*Test:* Section: "Test Plan: U-Boot Boot from QSPI Flash".
2. Support the U-Boot standard QSPI commands (the `sf_` commands family) for QSPI Flash.
  - *Rationale:* Explicit customer requirement.  
*Implementation:* Section: "Design: U-Boot `sf_` Commands".  
*Test:* Section: "Test Plan: U-Boot `sf_` Commands".
3. Store the U-Boot environment in QSPI Flash.
  - *Rationale:* Explicit customer requirement.  
*Implementation:* Section: "Design: U-Boot Environment in QSPI Flash".  
*Test:* Section: "Test Plan: U-Boot Environment in QSPI Flash".
4. Support installation of images to QSPI Flash from SD Card from the U-Boot command line interface.
  - *Rationale:* Explicit customer requirement.  
*Implementation:* Section: "Design: U-Boot Install Images to QSPI Flash".  
*Test:* Section: "Test Plan: U-Boot Install Images to QSPI Flash".
5. Support Linux boot from QSPI Flash, in the following configuration:
  - kernel image loaded from QSPI Flash to RAM for execution;
  - `dtb` image loaded from QSPI Flash into RAM for execution;
  - root file system mounted in QSPI Flash as the read-write Flash file system (UBIFS).

*Rationale:* Explicit customer requirement.  
*Implementation:* Section: "Design: Linux Boot from QSPI Flash".  
*Test:* Section: "Test Plan: Linux Boot from QSPI Flash".
6. Support QSPI Flash in Linux, using a newly developed device driver following the structure of the following existing device driver: `fsl-quadspi.c` (`{BSP-ROOT}/linux/drivers/mtd/spi-nor/fsl-quadspi.c`). This must include support for Linux Flash file system.
  - *Rationale:* Explicit customer requirement.  
*Implementation:* Section: "Design: Linux Device Driver for QSPI Flash and Flash File System".  
*Test:* Section: "Test Plan: Linux Device Driver for QSPI Flash and Flash File System".

## 2.2. Detailed Non-Requirements

The following are the non-requirements for this project that may otherwise not be obvious:

1. Support for any Flash devices other than the QSPI Flash device present on the NXP i.MX RT1050 EVKB board is not required.
  - *Rationale:* Costs reduction measure.
2. Support for Linux boot scenarios other than the one listed in Section: "Detailed Requirements" is not required.
  - *Rationale:* Costs reduction measure.

## 3. Design

### 3.1. Design: U-Boot Boot from QSPI Flash

A dedicated configuration file `mxrt1050-evk-sfboot_defconfig` will be added to U-Boot to support boot from QSPI Flash on the NXP i.MX RT1050. The standard build procedure will be used to generate the image `u-boot.flexspi` bootable from QSPI Flash:

```
make mxrt1050-evk-sfboot_config
make
```

The `u-boot.flexspi` image must be programmed to the QPSI flash on the NXP i.MX RT1050 EVKB board at offset 0. The image consists of the U-Boot itself and two i.MX RT1050-specific headers:

- Image Vector Table (IVT);
- The FlexSPI Configuration Block.

The Image Vector Table is generated by `mkimage` using the `board/freescale/mxrt105x-evk/imximage.cfg` configuration file.

The The FlexSPI Configuration Block is compiled from the `board/freescale/mxrt105x-evk/flexspi_cb.c` file. This file contains a definition of the `flexspi_nor_config_t` structure, as per the i.MX RT1050 Processor Reference Manual.

The default configuration will be set up to support the ISSI QSPI Flash installed on the EVKB board.

### 3.2. Design: U-Boot `sf_` Commands

The standard U-Boot `sf` commands will be enabled in the U-Boot configuration to support the SPI Flash read, erase and write operations.

### 3.3. Design: U-Boot Environment in QSPI Flash

Whenever the `mxrt1050-evk-sfboot` configuration is selected in U-Boot, the U-Boot environment will be stored in the QSPI Flash.

The environment, along with the redundant environment copy, will be placed at the address range `0x50000 - 0x70000` in QSPI flash.

### 3.4. Design: U-Boot Install Images to QSPI Flash

The QSPI Flash device will be logically divided into 5 sections to store the software components of the system:

- 0x000000 - 0x050000 - U-Boot
- 0x050000 - 0x070000 - U-Boot Environment
- 0x070000 - 0x080000 - DTB Image
- 0x080000 - 0x480000 - Kernel Image
- 0x480000 - 0x800000 - Root File System

The following commands will be defined in the U-Boot environment to update the above components:

- `sf_uboot_update` - Update the U-Boot section
- `sf_dtb_update` - Update the DTB section
- `sf_kernel_update` - Update the Kernel section
- `sf_rootfs_update` - Update the RootFS section

All the `sf*_update` commands will read images from the FAT FS partition on SD-card and install them to the corresponding section in QSPI Flash. The names of the images are defined by the following U-Boot environment variables:

- `uboot` - File name for the U-Boot image, default is `u-boot.flexspi`
- `dtb` - File name for the DTB image, default is `rootfs_ubi.dtb`
- `image` - File name for the Kernel image, default is `rootfs_ubi.uImage`
- `rootfs` - File name for the RootFS image, default is `rootfs.ubi`

The `sf*_update` commands will be available in the `mxrt1050-evk-sfboot` configuration when booting from QSPI Flash. If there is no U-Boot installed in QSPI Flash yet, the user can use the regular `mxrt1050-evk` configuration to boot from SD-card and make the first installation of U-Boot to the QSPI Flash. The following is the instruction on how to build the U-Boot image to boot from SD-card with write support to QSPI flash:

1. Switch to the regular `mxrt1050-evk` configuration.
2. Run `make menuconfig` to enable the `FSL_FLEXSPI`, `SPI_FLASH`, `SPI_FLASH_ISSI` and `CMD_SF` configuration options.
3. Build the `u-boot-dtb.imx` image and install it to the SD-card.

Note that only the `sf erase` and `sf write` operation supported when booting from SD-card. The `sf read` command is available but can return wrong data, when booting from SD card. This boot mode is used only for the first installation of U-Boot to QSPI Flash. `sf read` is fully supported when booting from the QSPI Flash.

### 3.5. Design: Linux Boot from QSPI Flash

The separate project `projects/rootfs_ubi` will be created to demonstrate booting Linux from QSPI flash. The following main feature will be enabled in the new project:

- Support for QSPI flash will be enabled in the kernel configuration.
- `initramfs` will be disabled in the kernel configuration. Instead the root filesystem will be mounted on an UBIFS file system in QSPI Flash.
- The kernel and the DTB images will be built separately, outside of the `mkimage` multi-part image.

To implement these features the following options will be added to the common build rules and will be used in Makefile for the `rootfs_ubi` project:

- `RFS_BUILD_DIR` - temporary directory to build the root file system image
- `UBI_IMAGES` - tells the make to build the file system image
- `MKFSUBIFS_FLAGS` - Flash-specific flags for the `mkfs.ubifs` utility
- `UBINIZE_FLAGS` - Flash-specific flags for the `ubinize` utility
- `SEPARATE_DTB` - tells the make not to build the multi-part image but save the DTB separately.

### 3.6. Design: Linux Device Driver for QSPI Flash and Flash File System

An `fsl_flexspi.c` driver will be added to the Linux device drivers.

The driver will provide an API compatible with the standard `SPI-NOR` framework in the kernel similar to the existing `fsl_qspi.c` driver. The QSPI Flash will be available in Linux as a standard `MTD` device.

Support for Linux Flash file systems does not require changes to the kernel.

## 4. Test Plan

### 4.1. Secure Download Area

The downloadable materials developed by this project are available from a secure Web page on the Emcraft Systems web site. Specifically, proceed to the following URL to download the software materials:

- <https://www.emcraft.com/imxrt1050/rm2595>

The page is protected as follows:

- Login: `imxrt1050`
- Password: *CONTACT EMCRAFT FOR DETAILS*

### 4.2. Downloadable Files

The following files are available from the secure download area for this release:

- `u-boot.flexspi` - U-Boot image installable to QSPI Flash.
- `u-boot-dtb.imx` - U-Boot image installable to SD-card with support for `sf_*` commands; this image allows booting from SD Card and installing U-Boot to QSPI Flash.
- `rootfs_ubi.dtb` - Linux device tree.
- `rootfs_ubi.uImage` - Linux kernel.
- `rootfs.ubi` - UBIFS image with Linux rootfs.
- `u-boot.patch` - Source code patch to U-Boot.
- `linux.patch` - Source code patch to Linux.
- `projects.patch` - Source code patch to `projects/`.

### 4.3. Test Set-Up

#### 4.3.1. Hardware Set-Up

The following hardware set-up is required for execution of the test plan in this project:

- A development host Linux PC.
- The NXP i.MX RT1050 EVKB board with serial console connected to PC.
- The following hardware reworks are required on the NXP i.MX RT1050 EVKB board to enable the QSPI Flash, as described in section 2.7 of the NXP IMXRT1050 EVKB Board Hardware User's Guide:
  - Remove resistors: R356, R361 - R366
  - Weld 0Ω resistors: R153 - R158.
- SD-card as the media to transfer the images from the development host to the target board.

### 4.3.2. Software Set-Up

#### *U-Boot Build:*

1. Apply the U-Boot patch from the top of the fresh `linux-cortexm` installation:

```
$ cd u-boot
$ patch -p1 < ../u-boot.patch
```

2. Build the bootable SD-card image with support for the `sf_*` commands for the first U-Boot installation to QSPI Flash:

1. Enable the default configuration for the IMXRT1050 EVK board

```
$ make distclean
$ make mxrt105x-evk_config
```

2. Run `menuconfig` and enable the `FSL_FLEXSPI`, `SPI_FLASH`, `SPI_FLASH_ISSI` and `CMD_SF` configuration options:

```
$ make menuconfig
Symbol: FSL_FLEXSPI [=y]
Prompt: Freescale Flex SPI controller
Location:
  -> Device Drivers
(1) -> SPI Support
Symbol: SPI_FLASH [=y]
Type : boolean
Prompt: Legacy SPI Flash Interface support
Location:
  -> Device Drivers
  -> SPI Flash Support
Symbol: SPI_FLASH_ISSI [=y]
Type : boolean
Prompt: ISSI SPI flash support
Location:
  -> Device Drivers
  -> SPI Flash Support
  -> Legacy SPI Flash Interface support (SPI_FLASH [=y])

Symbol: CMD_SF [=y]
Type : boolean
Prompt: sf
Location:
  -> Command line interface
  -> Device access commands
```

3. Build U-Boot:

```
$ make
```

4. Install the resultant image to the connected SD-card:

```
$ sudo dd if=u-boot-dtb.imx of=/dev/sdX bs=1k seek=1
$ sync
```

3. Build the U-Boot image bootable from QSPI Flash

## 1. Configure and build U-Boot for QSPI Flash:

```
$ make distclean
$ make mxrt105x-evk-sfboot_config
$ make
```

## 2. Copy the resultant image to the FATFS partition on the SD-card:

```
$ sudo mount /dev/sdX1 ~/tmp/
$ sudo cp u-boot.flexspi ~/tmp/
$ sudo umount ~/tmp/
```

*Linux Build:*

## 1. Apply the Linux and projects/ patches:

```
$ cd linux
$ patch -p1 < ../linux.patch
$ cd ../projects
$ patch -p1 < ../projects.patch
```

## 2. Build the rootfs\_ubi project:

```
$ cd rootfs_ubi
$ make
```

## 3. Copy the resultant images to the FATFS partition on the SD-card:

```
$ sudo mount /dev/sdX1 ~/tmp/
$ sudo cp rootfs_ubi.uImage rootfs_ubi.dtb rootfs.ubi ~/tmp/
$ sudo umount ~/tmp/
```

*Prebuilt Binaries:* For convenience, the prebuilt binaries resulting from the above build procedure are available in the area documented in Section: "Downloadable Files"

**4.4. Detailed Test Plan**

## 4.4.1. Test Plan: U-Boot Boot from QSPI Flash

The following step-wise test procedure will be used:

1. Power off the target board.
2. Set-up the SW7 switch on the target board to boot from SD-card (SW7/1 = ON, SW7/2 = OFF, SW7/3 = ON, SW7/4 = OFF)
3. Insert the SD-card prepared in Section: "Software Set-Up" and power on the board.
4. Stop U-Boot at the command monitor.
5. Run the following commands to install U-Boot to QSPI Flash:

```
=> sf probe 0
=> sf erase 0 0x50000
=> fatload mmc 0 ${loadaddr} u-boot.flexspi
=> sf write ${loadaddr} 0 ${filesize}
```

6. Power off the target board.
7. Set-up the SW7 switch on the target board to boot from QSPI Flash (SW7/1 = OFF, SW7/2 = OFF, SW7/3 = ON, SW7/4 = OFF)
8. Remove the SD-card and power on the board.
9. Validate that U-Boot has successfully booted from QSPI Flash.



## 4.4.2. Test Plan: U-Boot sf\_ Commands

The following step-wise test procedure will be used:

1. Boot U-Boot from QSPI Flash.
2. Probe the QSPI Flash. Make sure that the correct Flash info is printed out to the console:

```
=> sf probe 0
SF: Detected is25wp064a with page size 256 Bytes, erase size 64 KiB, total 8 MiB
=>
```

3. Read the U-Boot partition to RAM:

```
=> sf read ${loadaddr} 0 0x50000
device 0 offset 0x0, size 0x50000
SF: 327680 bytes @ 0x0 Read: OK
=>
```

4. Make sure the FlexSPI Configuration Block is at the beginning of the read data: the first 4 symbols must be "FCFB" :

```
=> md ${loadaddr} 1
80007fc0: 42464346                                FCFB
=>
```

5. Erase 5 sectors in the middle of QSPI Flash:

```
=> sf erase 0x300000 0x50000
SF: 327680 bytes @ 0x300000 Erased: OK
=>
```

6. Write the U-Boot image to the erased area:

```
=> sf write ${loadaddr} 0x300000 0x50000
device 0 offset 0x300000, size 0x50000
SF: 327680 bytes @ 0x300000 Written: OK
=>
```

7. Read it back to a separate area in RAM:

```
=> sf read 0x81000000 0x300000 0x50000
device 0 offset 0x300000, size 0x50000
SF: 327680 bytes @ 0x300000 Read: OK
=>
```

8. Make sure that the data in 2 areas are identical:

```
=> cmp.b ${loadaddr} 0x81000000 0x50000
Total of 327680 byte(s) were the same
=>
```

## 4.4.3. Test Plan: U-Boot Environment in QSPI Flash

The following step-wise test procedure will be used:

1. Remove SD-card and boot U-Boot from QSPI Flash.
2. Define and save a test variable:

```
=> setenv testvar testval
=> saveenv
Saving Environment to SPI Flash...
SF: Detected is25wp064a with page size 256 Bytes, erase size 64 KiB, total 8 MiB
Erasing SPI flash...Writing to SPI flash...done
Valid environment: 2
=>
```

## 3. Reset the board:

```
=> reset
```

## 4. Make sure the test variable exists and has the correct value:

```
=> print testvar
testvar=testval
=>
```

## 4.4.4. Test Plan: U-Boot Install Images to QSPI Flash

The following step-wise test procedure will be used:

1. Boot U-Boot from QSPI Flash.
2. Insert the SD-card prepared in Section: "Software Set-Up" to the SD Card holder.
3. Reset the environment:

```
=> env default -f -a
=> saveenv
=>
```

## 4. Install the software components:

```
=> sf probe 0
SF: Detected is25wp064a with page size 256 Bytes, erase size 64 KiB, total 8 MiB
=> run sf_uboot_update
reading u-boot.flexspi
256000 bytes read in 78 ms (3.1 MiB/s)
SF: 327680 bytes @ 0x0 Erased: OK
device 0 offset 0x0, size 0x3e800
SF: 256000 bytes @ 0x0 Written: OK
=> run sf_dtb_update
reading rootfs_ubi.dtb
10438 bytes read in 25 ms (407.2 KiB/s)
SF: 65536 bytes @ 0x70000 Erased: OK
device 0 offset 0x70000, size 0x28c6
SF: 10438 bytes @ 0x70000 Written: OK
=> run sf_kernel_update
reading rootfs_ubi.uImage
2957824 bytes read in 693 ms (4.1 MiB/s)
SF: 4194304 bytes @ 0x80000 Erased: OK
device 0 offset 0x80000, size 0x2d2200
SF: 2957824 bytes @ 0x80000 Written: OK
=> run sf_rootfs_update
reading rootfs.ubi
1310720 bytes read in 320 ms (3.9 MiB/s)
SF: 3670016 bytes @ 0x480000 Erased: OK
device 0 offset 0x480000, size 0x140000
SF: 1310720 bytes @ 0x480000 Written: OK
=>
```

## 4.4.5. Test Plan: Linux Boot from QSPI Flash

The following step-wise test procedure will be used:

1. Remove the SD Card from the SD holder. Reset the board and make sure it automatically boots up to busybox:

```
=> reset
...
init started: BusyBox v1.24.2 (2018-06-18 18:30:51 MSK)
/ #
```

## 4.4.6. Test Plan: Linux Device Driver for QSPI Flash and Flash File System

The following step-wise test procedure will be used:

1. Boot from QSPI Flash up `busybox`.
2. Make sure that the UBIFS partition is mounted as the Linux root file system:

```
/ # mount
ubi0:rootfs on / type ubifs (rw,relatime)
devtmpfs on /dev type devtmpfs (rw,relatime,mode=0755)
proc on /proc type proc (rw,relatime)
sysfs on /sys type sysfs (rw,relatime)
devpts on /dev/pts type devpts (rw,relatime,gid=5,mode=620,ptmxmode=000)
/ #
```

3. Make copy of the `busybox` binary in the Flash-based root file system and reboot:

```
/ # cp /bin/busybox /
/ # reboot
```

4. After reboot, make sure that the original file and the copy are identical:

```
/ # md5sum busybox
099afa6f383f8186b5e849ecc2efc4d0 busybox
/ # md5sum /bin/busybox
099afa6f383f8186b5e849ecc2efc4d0 /bin/busybox
/ #
```